

# Cisco Phone Guide

## 7941/61/7X Models



- Line Buttons- Will display the phone lines you have access to.
  - Messages- Will direct you to the Voicemail Service
  - Directory- Will display the directory menu. Items included in the directory are: Missed, Received, & Placed calls.
  - Settings- allow you to personalize your phone. Options included in settings are: display contrast, ring type, & ring volume.
  - Volume Control- during a call, use the volume control to increase or decrease the volume of the h&set & speaker phone.
  - Services- allow you to access My Address Book & My Speed Dials.
  - Scroll- navigate through the directories & settings.
  - Soft Keys- will change depending on the state of the phone is in (in or not in use).
- \*Color Screens are touch screens

### Accessing Outside Lines

- Lift the Handset & dial the number preceded by '9' OR
- Press the Line, Speaker, Headset, **NewCall** buttons & dial the number preceded by '9'

### Placing a Call on Hold:

- During a call, press the **Hold** soft key
- To return to the call, highlight the call & press the **Resume** soft key
- To place another call from that line, press the **New Call** soft key

### Parking a Call:

- During a call, press the **Park** soft key
- Call parked at will display on bottom of phone with number call is at

- To get the call back, from any phone, take the phone offhook and enter the number the call was parked at

### Transferring a Call:

- Press the **Transfer** soft key (caller is put on hold automatically)
- Dial the number to transfer the call to
- When you hear ringing press **Transfer** button OR wait to announce call then press **Transfer** a second time
- ❖ To retract the transfer, press **End Call** prior to the pressing **Transfer** the second time, then press **Resume** to get the call off Hold
- ❖ To Transfer Directly to someone's voicemail box dial \*XXXX where XXXX is their number.

### Using Corporate Directory:

- Press the *Directory* button
- Select Corporate Directory
- Enter a portion of the name & press Search
- Select the user & press **Dial**

### Conference Calls:

- During a call, press the **More** soft key & then the **Confrn** soft key.
- Call the other party
- When the call connects, press the **Confrn** soft key again to add this party to the call
- ❖ To end the Conference prior to getting the third party on line, press **End Call** prior to the pressing **Confrn** the second time, then press **Resume** to get the call off Hold
- Continue the previous steps to add additional parties to the conference call

### Call History:

- Press the **Directories** button to display the directory menu:
- Use the *Scroll* key to highlight the desired history then press the **Select** soft key
- Use the *Scroll* key to highlight the desired number then press the **Dial** soft key place a call

- Use the **EditDial** key to change the number to dial out if needed (may need to add 9, 91, or remove some digits)

### Ignoring a Call:

- When a call is ringing in, press the **iDivert** softkey to immediately redirect them to VM

### Do Not Disturb

- To turn your phone off from ringing when the phone is idle press the **DND** softkey this will turn off the ringer on your phone but it will flash when you received new calls

### Forward Your Phone

- While your phone is idle press the CFWDALL Soft Key this will give you dial tone allowing you to enter the number. Once the system recognizes it as a valid number it will be activated. To disable press the CFWDALL Soft Key to turn it off

### Ringer Volume:

- When the phone is **OnHook**, you can change the ringer volume by pressing the volume control up or down repeatedly.
- Change the call volume by changing the volume while on a call, then press Save to retain the setting for the next call

### Emergency Dialing:

- All phones can call both 911 and 9911 – either number will place a call to 911 emergency services.

### Voicemail Numbers:

#### From outside:

- 540-831-7750 – Press \*

#### From your phone:

- Press the Messages key
- When voicemail picks up enter followed by PIN followed by #.
- Default PIN: 12345 or use your existing PIN